

# Petunjuk Instalasi InVue ADH2300



Rev2 9.12.2018

## Bagian InVue

---



KETERANGAN  
Paket Poles



KETERANGAN  
Kain Mikrofiber



1 Buka paket poles.



2 Pencet sedikit senyawa pemoles ke bagian belakang perangkat tempat sensor akan dipasang.



3 Pakai kain mikrofiber untuk menggosok senyawa pemoles dengan kuat ke perangkat selama 15-20 detik.



4 Pakai kain mikrofiber untuk menggosok bagian belakang perangkat dengan kuat.

**Catatan:** Perbedaan visual mungkin tidak nampak.

5 Perangkat sekarang siap untuk dipasang pelat LSE atau perekat lain yang dipasang ke permukaan.

**Catatan:** Ulangi proses untuk perangkat tambahan apa pun.

## Adhesive Polish Kit (ADH2300)

---

- The polish kit includes a polishing compound and microfiber cloth to remove a microscopic layer that is not visible to the naked eye. The polish prepares the surface to accept the adhesive without changing the appearance.
- There is enough compound in one packet to be used on at least 5 phones at a time. One packet included per unit.
- ADH2300 is the only solution that will work for all devices, and it must always be used for the following phone types:
  - iPhone
  - Samsung Galaxy
  - Google Pixel
  - Moto One
  - Huawei Mate