

# Hướng dẫn lắp đặt InVue ADH2300

# InVue®

Rev2 9.12.2018

## ▼ Các bộ phận InVue

---



**MÔ TẢ**  
Gói đánh bóng



**MÔ TẢ**  
Khăn vải sợi nhỏ

---

# InVue®

Dịch vụ khách hàng InVue **888.554.6883** (tùy chọn 2)  
Thời gian: 8h sáng- 5h chiều EST



1 Mở gói đánh bóng.



2 Bóp một lượng nhỏ hợp chất đánh bóng vào mặt sau của thiết bị, nơi sẽ đặt cảm biến.



3 Sử dụng khăn vải sợi nhỏ để chắc chắn chà xát đánh bóng hợp chất trên thiết bị trong 15-20 giây.



4 Sử dụng khăn vải sợi nhỏ để chắc chắn đánh bóng mặt sau của thiết bị.

**Lưu ý:** Sự khác biệt về hình ảnh có thể không rõ ràng.

5 Thiết bị hiện đã sẵn sàng để dán một tấm LSE hoặc chất kết dính khác lên bề mặt.

**Lưu ý:** Lặp lại quy trình cho bất kỳ thiết bị bổ sung nào.

## Adhesive Polish Kit (ADH2300)

---

- The polish kit includes a polishing compound and microfiber cloth to remove a microscopic layer that is not visible to the naked eye. The polish prepares the surface to accept the adhesive without changing the appearance.
- There is enough compound in one packet to be used on at least 5 phones at a time. One packet included per unit.
- ADH2300 is the only solution that will work for all devices, and it must always be used for the following phone types:
  - iPhone
  - Samsung Galaxy
  - Google Pixel
  - Moto One
  - Huawei Mate