InVue Installation Instructions ADH2300



Rev2 9.12.2018





DESCRIPTION Polish Packet



DESCRIPTION Microfiber Cloth









Open the polish packet.



2

Squeeze a small amount of polishing compound onto the back of the device where the sensor will be placed.



Use the microfiber cloth to firmly rub the polishing compound onto the device for 15-20 seconds.

3



Use the microfiber cloth to firmly buff the back of the device.

Note: A visual difference may not be apparent.



The device is now ready to have an LSE plate or other adhesive applied to the surface.

Note: Repeat the process for any additional devices.

ÌnVue,



- The polish kit includes a polishing compound and microfiber cloth to remove a microscopic layer that is not visible to the naked eye. The polish prepares the surface to accept the adhesive without changing the appearance.
- There is enough compound in one packet to be used on at least 5 phones at a time. One packet included per unit.
- ADH2300 is the only solution that will work for all devices, and it must always be used for the following phone types:
 - o iPhone
 - o Samsung Galaxy
 - Google Pixel
 - o Moto One
 - o Huawei Mate

