

WS2 Apple Watch Tray Sensors ZW1051-52 Installation



- 1 Use a provided alcohol wipe to clean the bottom and sides of the wearable. Allow it to dry completely.



- 2 Ensure that the red pull tabs lay flat against the bottom of the tray sensor.



- 3 Insert the dial side of the watch into the tray sensor so that the corners of the wearable sit against the adhesives.



- 4 Pivot the other side of the wearable down into the tray sensor.



- 5 Flip the wearable over and pull the 4 red tabs out through the opening in the bottom of the tray sensor.



- 6 Press the 4 corners of the tray sensor against the wearable for at least 10 seconds.



- 7 Use the provided alcohol wipe to clean the area where the stand will be placed. Allow it to dry completely.



- 8 Plug the tray sensor into the bottom of the WS2 stand.

WS2 Apple Watch Tray Sensors ZW1051-52 Installation



- 9 Peel the clear film from the adhesive on the bottom of the stand.



- 10 **Optional:** Route the stand's cable through a hole or slot in the fixture.




- 11 Place the stand onto the fixture and apply pressure for at least 10 seconds.



- 12 If using the charging cradle ZW1005, remove the top pad.



- 13 Use an alcohol wipe to remove any adhesive residue from the depression. Allow it to dry completely.



- 14 Remove the backing from the included aligner pad.



- 15 Place the aligner pad into the depression on the charging cradle and apply pressure for at least 10 seconds.



- 16 Place the wearable and tray sensor onto the charging cradle.

SD0896 Rev1 09/28/22