
WS2/W2000 Apple Watch Flex Tray Sensors ZW1921-22 Installation







Ensure that the red pull tabs lay flat against the bottom of the tray sensor.



3

Insert the dial side of the watch into the tray sensor so that the corners of the wearable sit against the adhesives.



Pivot the other side of the wearable down into the tray sensor.



Flip the wearable over and pull the 4 red tabs out through the opening in the bottom of the tray sensor.



Press the 4 corners of the tray sensor against the wearable for at least 10 seconds.

6



Lift the band clamp/sensor end from the stand.



8

Pull enough cable to allow for easy installation. Close the cable stop clip over the cable to prevent it from recoiling.



5

7

WS2/W2000 Apple Watch Flex Tray Sensors ZW1921-22 Installation



9a Optional:

If present, remove the existing band clamp from the sensor end by loosening the screw with a TT8 bit.

9b



Slide the sensor end from the

existing band clamp.



10 Slide the provided band clamp onto the sensor end so that the screw holes align.



With the wearable facing down, place the back band into the band clamp as shown.





Plug the sensor on the flex tray into the sensor end of the stand.



13 Close the band clamp over the band.



Use a TT8 bit to tighten the screw on the band clamp.





If using the charging cradle ZW1005, remove the top pad.




For technical assistance call **NA / LATAM** // 704.752.6513 • 888.55.INVUE **EMEA** // +31.23.8900150 **APAC** // +852.3127.6811

14

WS2/W2000 Apple Watch Flex Tray Sensors ZW1921-22 Installation







17 Remove the backing from the included aligner pad.



18 Place the aligner pad into the depression on the charging cradle and apply pressure for at least 10 seconds.



19 Remove the cable stop clip from the cable.





InVue

Place the wearable and tray sensor onto the charging cradle.

SD0900 Rev0 09/23/22

